

# Instructions for Using LJ-3085 Insert-Runner™

Screw the threaded end of the Insert-Runner™ into the threaded hole in the insert and drive the insert until it is slightly deeper than flush with the surface.

Note: Use only 1/2" or larger drill motor with side handle to drive the inserts. A 3/8" wrench may also be used with the Insert-Runner™ to drive the insert.

